

# LoJack Early Warning For Motorcycles Key Pass Battery Replacement

To ensure optimum performance of your system and uninterrupted coverage, we recommend changing your batteries every six months or when you change the batteries in other household items like your smoke detectors.

**You will need one Lithium watch battery (#CR-2032), which can be purchased at most retail stores and electronic retailers.**



## 1. Remove the Screw

Remove the screw from the Key Pass with a screwdriver.



## 2. Open Key Pass

Gently pry apart two halves of the Key Pass. You will notice a circular battery retained by a battery holder.



## 3. Remove Old Battery

Push the battery out of its holder using a non-metal tool. The battery **MUST** be installed with the + sign facing up. The red light on the face of the Key Pass should flash several times immediately after properly installing a battery.



## 4. Close the Key Pass

Reassemble the Key Pass by snapping the two halves of the base together and screw the two halves back together. Make sure that the battery LED indicator is visible through the hole in the Key Pass.